



Removing Olympus FE-210 Batteries

Step by step guide to replacing batteries in the Olympus FE-210.


Written By: Matt



INTRODUCTION

Removing and replacing the battery is usually the first step towards fixing your camera.

Step 1 — Battery



- The battery compartment is located on the bottom side of the camera. Push the button in, and slide the cover to get access to the batteries.

Step 2



- The batteries will slide right out.
- ☑ When putting new batteries in, make sure they are pointing the right direction.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-09 10:00:21 PM.